



## Ceiling

# Windtight and rainproof on the outside

### Mounting moisture protection on wooden ceiling elements



- Clean the substrate
- Substrate must be dry, free from dust and grease and not adhesive repellent



- Align Wetguard with markings such as print out or chalk line
- Overlap Wetguard by 15 cm, at least more than 10 cm
- Roll Wetguard back again



- Release wide backing strips, beginning with slotting, and pull through under the roll
- Press Wetguard onto the substrate



- Remove the backing strips, unroll Wetguard and press firmly onto the substrate with a brush or surface wiper



5

### For overlaps

- Overlap Wetguard by 15 cm, at least more than 10 cm
- Remove the thin backing strip and press down well



6

### It looks like this

- Timber ceiling element adhered with Wetguard



A

- Bond element connecting joints e.g. butt boards etc. with Wetguard 390 mm



Wetguard® 200 SA

P. 149



## Ceiling

# Windtight and rainproof on the outside

### Connections / intersections



- Seal connections to mineral substrates with Wigluv 100 or Wigluv 150
- Pre-treat substrates in accordance with the SIGA instruction manual



- Make the connection to timber/timber materials with Wigluv 100, Wigluv 150 or Wetguard 390 mm
- Pre-treat substrates in accordance with the SIGA instruction manual



**Dockskin® 100** P. 127

**Dockskin® 200** P. 138

**Wigluv® 100 & 150** P. 130