



Wall: Solid construction
Airtight on the inside

Window on concrete floor



Initial situation:

- Floor-deep window / façade element installed



- Clean the substrates to be bonded
- Apply Dockskin 200
- Use a roller to apply thinly and over the entire surface of the concrete floor
- Wait until Dockskin 200 is completely dry



- Roll out Fentrim to required length
- Add approx. 15–20 cm on both sides (to form sides of trough)
- Cut Fentrim to required length



- Remove about 10 cm of 1st backing strip and stick to window / façade element using a small area of adhesion
- Extend approx. 15–20 cm on left and right

Wall: Solid construction
Airtight on the inside



- Remove 1st backing strip little by little
- Align and fix tension-free
- Press on firmly



- Remove more backing strip little by little
- Bend without introducing tension
- Press on firmly



How it should look:

- Floor-deep window / façade element connected to concrete floor



Dockskin® 200

Fentrim® 330 grey